Kochplatte

10027875
10027876
10027877
10027878
10027879

KLARSTEIN

Sehr geehrter Kunde,

Wir gratulieren Ihnen zum Erwerb Ihres Klarstein Gerätes. Lesen Sie die folgenden Anschluss- und Anwendungshinweise sorgfältig durch und befolgen Sie diese, um möglichen technischen Schäden vorzubeugen. Für Schäden, die durch Missachtung der Sicherheitshinweise und unsachgemäßen Gebrauch entstehen, übernehmen wir keine Haftung.

Inhaltsverzeichnis

Technische Daten 2
Sicherheitshinweise 2
Vor dem ersten Betrieb 3
Inbetriebnahme 3
Pflege und Wartung 4
Hinweise zur Entsorgung 4
Konformitätserklärung 4

Technische Daten

Artikelnummer	10027875, 10027876, 10027877
Stromversorgung	220-240 V ~ 50-60 Hz
Leistung	2400 W (2 x 1200 W)
Abmessungen	570 mm (Breite) x 265 mm (Tiefe) x 105 mm (Höhe)
Gewicht	3 kg

Artikelnummer	10027878, 10027879
Stromversorgung	220-240 V ~ 50-60 Hz
Leistung	1200 W
Abmessungen	340 mm (Breite) x 265 mm (Tiefe) x 105 mm (Höhe)
Gewicht	1.7 kg

Sicherheitshinweise

- Lesen Sie sich alle Hinweise sorgfältig durch und bewahren Sie die Bedienungsanleitung zum Nachschlagen gut auf.
- Fassen Sie nicht auf die heiße Kochfläche. Fassen Sie nur die Regler an.
- Um sich vor Stromschlägen zu schützen, tauchen Sie das Netzkabel, den Stecker oder die Kochplatte nie komplett in Wasser oder andere Flüssigkeiten.
- Benutzen Sie die Kochplatte in Anwesenheit von Kindern nur unter Aufsicht.
- Ziehen Sie den Stecker aus der Steckdose, wenn Sie das Gerät nicht mehr benutzen oder reinigen. Lassen Sie das Gerät komplett abkühlen, bevor Sie Teile abnehmen.
- Benutzen Sie das Gerät nicht, wenn das Netzkabel oder der Stecker beschädigt sind, falls es nicht ordnungsgemäß funktioniert oder in irgendeiner Weise beschädigt wurde. Reparaturen und Wartung am Gerät dürfen nur von geschulten Fachkräften ausgeführt werden.
- Benutzen Sie kein Zubehör, das nicht vom Hersteller zugelassen ist. Sie könnten sich verletzen.
- Benutzen Sie das Gerät nur in Innenräumen und nicht im Freien.
- Achten Sie darauf, dass das Netzkabel nicht über scharfe Kanten oder heiße Oberflächen verläuft.
- Stellen Sie die Kochplatte nicht in der Nähe von Gas- und Elektroherden oder Öfen auf.
- Passen Sie auf, dass Sie sich nicht verletzen, wenn Sie Töpfe oder Pfannen mit heißem Fett oder anderen heißen Inhalten bewegen.
- Schließen den Netzstecker zuerst am Gerät an, bevor Sie ihn in die Steckdose stecken. Wenn Sie mit dem Kochen fertig sind, drehen Sie die Regler komplett herunter und ziehen Sie dann den Stecker aus der Steckdose.
- Benutzen Sie die Kochplatte nicht anders als in der Bedienungsanleitung beschrieben.

Hinweise zum Anschluss

- Wir empfehlen Ihnen, kein Verlängerungskabel zu benutzen, da es überhitzen und Brand verursachen könnte. Falls sie dennoch ein Verlängerungskabel benutzen, achten Sei darauf, dass die angegebene Leistungsaufnahme mindestens so hoch ist, wie die der Kochplatte.
- Lassen Sie das Netzkabel nicht über die Arbeitsfläche hängen, damit Kinder nicht daran ziehen und niemand darüber stolpert.
- Um Überladung und Kurzschlüsse zu vermeiden, schließen Sie keine anderen Geräte mit hohem Stromverbrauch an dieselbe Steckdose an.
- Verlegen Sie das Netzkabel nicht unter Teppichen oder Decken und achten Sie darauf, dass es nicht im Weg liegt.
- Versuchen Sie nicht den elektrischen Sicherheitsschalter selbst zu reparieren. Lassen Sie ihn von einem Fachbetrieb reparieren oder ersetzen.
- Kinder, physisch und körperlich eingeschränkte Menschen sollten das Gerät nur benutzen, wenn sie vorher von einer Aufsichtsperson ausführlich mit den Funktionen und den Sicherheitsvorkehrungen vertraut gemacht wurden.
- Achten Sie darauf, dass Kinder nicht mit dem Gerät spielen.
- Kochplatte und Geräteoberfläche werden beim Kochen heiß.
- Schließen Sie die Kochplatte nicht an eine ferngesteuerte Steckdose oder einen externen Timer an.
- Falls die Kochplatte gebrochen ist, nehmen Sie sie umgehend außer Betrieb, um Elektroschocks zu vermeiden.
- Wenn Sie die Kochplatte das erste Mal benutzen kann es leicht qualmen und etwas riechen, das ist ein normales Phänomen.

Hinweise zum Standort

- Stellen Sie die Kochplatte nicht in der Nähe von oder auf heißen Oberflächen auf.
- Versichern Sie sich, dass die Kochplatte auf einer stabilen, ebenen Oberfläche steht, um zu verhindern, dass Flüssigkeiten überlaufen und ins Gerät eindringen.
- Fassen Sie die Kochplatte nicht an, bis sie vollständig abgekühlt ist.

Vor dem ersten Betrieb

- Reinigen Sie die Kochplatte mit einem feuchten, weichen Lappen. Stellen Sie die Kochplatte auf einer stabilen, ebenen Oberfläche in der Nähe der Steckdose auf.
- Prüfen Sie vor der Benutzung die Spannung auf der Geräteplakette und schließen Sie das Gerät nur an Steckdosen an, die der Spannung des Geräts entsprechen. Achten Sie darauf, dass der Regler auf „OFF" steht, bevor Sie das Gerät anschließen.
- Benutzen Sie nur Pfannen und Töpfe mit flachen Böden, die einen maximalen Kontakt zur Herdoberfläche haben. Der optimale Durchmesser für Pfannen und Töpfe beträgt 18-22 cm.
- Halten Sie die Kochplatte trocken und sauber.
- Lassen Sie die Kochplatte im Betrieb und in Gegenwart von Kindern nie unbeaufsichtigt.

Inbetriebnahme

- Geben Sie Wasser und/oder Essen in den Topf. Um Überlaufen vorzubeugen, füllen Sie den Topf zu maximal 80% mit Wasser und/oder Essen.
- Setzen Sie einen Deckel auf den Topf und stellen Sie ihn auf die Kochplatte.
- Stecken Sie den Stecker in die Steckdose und drehen Sie den Temperaturregler auf „MAX". Die Kontrollleuchte zeigt an, dass die Kochplatte in Betrieb ist und heizt.
- Falls Sie die Kochplatte zum ersten Mal benutzen kann es sein, dass sie leicht qualmt. Das liegt an der schützenden Oberflächenbeschichtung der Kochplatte und gibt sich mit der Zeit.
- Es kann vorkommen, dass die Kontrollleuchte kurzzeitig erlischt, bevor das Wasser kocht. Das liegt am eingebauten Sicherheitsthermostat, der dafür sorgt, dass die Kochplatte nicht durch Dauerbetrieb überhitzt.
- Sobald Sie fertig mit dem Kochen sind, drehen Sie den Temperaturregler auf „OFF" und ziehen Sie den Stecker aus der Steckdose. Warten Sie bis die Kochplatte vollständig abgekühlt ist, bevor Sie sie bewegen oder reinigen.

Reinigung und Pflege

- Versichern Sie sich, dass die Kochplatte vom Stromkreis getrennt ist.
- Nachdem die Kochplatte vollständig abgekühlt ist, reinigen Sie die Platte mit einem milden Reiniger und einem weichen Lappen.
- Reinigen Sie die Kochplatte nicht, solange sie noch heiß ist.
- Verwenden Sie zur Reinigung keine harten Bürsten, Topfschwämme, Alkohol oder andere organische Lösemittel.
- Tauchen Sie die Kochplatte zur Reinigung nicht komplett in Wasser.
- Verstauen Sie die Kochplatte nach der Reinigung an einem kühlen Ort.

Hinweise zur Entsorgung

Befindet sich die linke Abbildung (durchgestrichene Mülltonne auf Rädern) auf dem Produkt, gilt die Europäische Richtlinie 2002/96/EG. Diese Produkte dürfen nicht mit dem normalen Hausmüll entsorgt werden. Informieren Sie sich über die örtlichen Regelungen zur getrennten Sammlung elektrischer und elektronischer Gerätschaften. Richten Sie sich nach den örtlichen Regelungen und entsorgen Sie Altgeräte nicht über den Hausmüll. Durch die regelkonforme Entsorgung der Altgeräte werden Umwelt und die Gesundheit ihrer Mitmenschen vor möglichen negativen Konsequenzen geschützt. Materialrecycling hilft, den Verbrauch von Rohstoffen zu verringern.

Konformitätserklärung

Hersteller: CHAL-TEC Vertriebs- + Handels GmbH, Wallstraße 16, 10179 Berlin.

CE

Dieses Produkt entspricht den folgenden Europäischen Richtlinien:
2004/108/EG (EMV)
2011/65/EU (RoHS)
2006/95/EG (LVD)

Dear Customer,

Congratulations on purchasing this Klarstein eqipment. Please read this manual carefully and take care of the following hints on installation and use to avoid technical damages. Any failure caused by ignoring the mentioned items and cautions mentioned in the operation and installation instructions are not covered by our warranty and any liability.

Contents

Technical Data 5
Safety Instructions 5
Before first Use 6
Getting Started 6
Cleaning and Care 7
Environment Concerns 7
Declaration of Conformity 7

Technical Data

Item number	**10027875, 10027876, 10027877**
Power supply	220-240 V ~ 50-60 Hz
Power	2400 W (2 x 1200 W)
Dimensions	570 mm (Width) x 265 mm (Depth) x 105 mm (Height)
Weight	3 kg

Item number	**10027878, 10027879**
Power supply	220-240 V ~ 50-60 Hz
Power	1200 W
Dimensions	340 mm (Width) x 265 mm (Depth) x 105 mm (Height)
Weight	1.7 kg

Safety Instructions

- Read all the safety and operating instructions carefully and retain them for future reference.
- Do not touch hot surfaces. Use handle or knobs.
- To protect against electrical shock do not immerse cord, plugs, or the whole unit in water or other liquid.
- Close supervision in necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunction or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge or table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to “off”, then remove plug from wall outlet.
- Do not use appliance for other than intended use.

CORRECT USE OF ELECTRICITY

- Use of an extension cord is not recommended as it may overheat and cause risk of fire. However, if an extension cord is used, the marked electrical rating of the extension cord should be at least as great as the electrical rating of the appliance, and the long cord should be arranged so that it will not drape over the countertop or tabletop where it can be pulled on by children or tripped over.
- To prevent overloading and blowing fuses, ensure that no other high power appliance is plugged into the same socket, or another socket which is connected in the same circuit.
- DO NOT PUT the cord under the carpet, blankets. Always keep the power cable away from walkway in room. DO NOT TRY TO REPAIR the broken fuse by yourself, the user should take the set to your local authorized maintenance center to replace it with the new one.
- The appliance is indoor use only.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- The surfaces are liable to get hot during use
- Appliances are not intended to be operated by means of an external timer or separate remote-control system
- When the appliance is not in use and before cleaning, unplug the appliance from the outlet.
- WARNING: If the surface is cracked, switch off the appliance to avoid the possibility of electric shock.
- The outer surface may get hot when the appliance is operating and first time use, there is a little smoke and smell, that is normal.

SAFETY IN OPERATION

- DO NOT OPERATE this hot plate near water sources or flammable liquids.
- DO NOT OPERATE this hot plate on or near any hot surface. (Hot plate, ectric stoves etc).
- Always operate this from an earthed domestic 220V-240 ~ 50/60 Hz power socket.
- Ensure the hot place is placed on a stable, secure surface to eliminate the possibility of tipping over or avoid any water in the appliance.
- Never try to touch the hot surface of this hot plate before it is cooled down.

Before first Use

- Clean the hot plate with a soft damp cloth. Place your hot plate on the level and stable surface near the electrical socket. Check that the voltage marked on the product corresponds with your supply voltage. Ensure the controller is in the "OFF" position before plug in.
- Always use flat bottom saucepans or containers that make close contact with the heating element. Ideally, the saucepans or containers should be 180-200mm in diameter. Keep the surface of the heating element clean and dry.
- Close supervision is extremely necessary when this hot plate is used by or near children.
- or invalids. Never operate this hot plate unattended.

Getting Started

- Put water and/or food in the container (The total amount of water and /or food should not exceed 80% of the container to avoid overflowing), put a lid on the container and place it on the hot plate. If there is smoke for the first use, that is normal. To make the unit heat without any pot about 10 Minutes before cooking.
- Connecting to the power supply socket. Turn the switch from "OFF" TO "MAX" position and the indicator light is on for working, the hot plate is in a state of heating.
- Two points to be reminded by the user when using the new hot plate:
- When using this hot plate for the first time, there may be a smell of smoke coming from the surface of the heating element. This is normal because of the invisible protective coating in production.
- Before the water is boiling, the indicator light on the hot plate may be temporary off due to the temporary disconnection of the thermostatic control.
- This is a safety issue for the working on the hot plate.
- When you have finished using the hot plate, turn the switch to "OFF" position and unplug it from the socket. Wait until the appliance is completely cooled down before moving or cleaning.

Cleaning and Care

- Make sure the plug is removed from the power supply socket.
- After the hot plate set is completely cooled down, clean it with the mild cleaner or gel-like cleaner by using soft cloth.
- PLEASE DO NOT CLEAN THE SET WHEN IT IS STILL HOT.
- DO NOT USE hard brushes, scratchy materials and/or alcohol, petrol or any organic cleaner for the cleaning purpose.
- Except the removable frying pan, do not immerse the main body in water to clean.
- Put the hot plate on the cool place right after the cleaning.

Environment Concerns

According to the European waste regulation 2002/96/EG this symbol on the product or on its packaging indicates that this product may not be treated as household waste. Instead it should be taken to the appropriate collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. For more detailled information about recycling of this product, please contact your local council or your household waste disposal service.

Declaration of Conformity

Producer: CHAL-TEC Vertriebs- + Handels GmbH, Wallstraße 16, 10179 Berlin.

CE

This product is conform to the following European Directives:
2004/108/EC (EMC)
2011/65/EU (RoHS)
2006/95/EC (LVD)